

Patchy Colours - Stains Colour appears uneven and non uniform.	
Cause	Prevention
Uneven sanding of the substrate with coarse sandpaper.	Use 180 or 240 grit sandpaper on an orbital sander to achieve a uniform base or if sanding by hand always sand with the grain of the wood.
Uneven stain application.	Apply the stain in an even wet application. Remove excess stain with a clean lint free cloth to achieve a uniform finished colour.
Stain applied too dry or with a thinner that dries too fast	Always use the correct thinner for the application technique. A slow thinner is required when a stain has to be wiped even over large areas. Apply the stain in a wet application using low air pressure.